

To ensure proper installation of FloorTac printable PVC film, please follow the recommendations listed below. Drytac recommends its Emerytex laminating films be paired with FloorTac to provide slip resistance.

## ROUTINE MAINTENANCE

1. Choose floor finish or wax that meets or exceeds the 0.5 Static Coefficient of Friction.
2. Clean the graphic.
3. Apply wax using the manufacturer's recommendations.
4. Do not use buffing equipment over the graphics unless they are waxed regularly.  
\* If high-speed, propane-type buffers are used, apply 4 - 6 coats of wax to graphic prior to buffing. This precaution will reduce the risk of the graphic's edge wearing prematurely.

## IMPORTANT NOTE:

Please refer to the FloorTac TDS and for more information. The technical information, recommendations and other statements contained in this document are based upon testing and experience Drytac believes to be reliable, but the accuracy and or completeness is not guaranteed. Drytac recommends a small test be performed to determine suitability beforehand. This document does not constitute a warranty of any kind.

**For more information, please contact your local Drytac office.**

© 2018 Drytac Corporation. E&OE.  
All other trademarks are the property of their respective owners.

## INSTALLATION INSTRUCTIONS

### RECOMMENDATIONS FOR INSTALLATION

1. The graphic should have a 0.25" (6mm) non-printed border and all corners should be rounded.
2. FloorTac may be used on commercial floor tiles, sealed wood, sealed concrete, waxed vinyl, marble, terrazzo, and ceramic tiles.
3. FloorTac must be applied indoors to clean floors in excellent condition. The floor surface must be clean and free of oil, grease, and coatings. The sealants, coatings, and paints must have excellent adhesion to the floor and it must not be loose or uneven.
4. Clean the floor thoroughly and allow it to dry prior to applying the graphic. Use an alcohol moistened, lint-free cloth to remove any grease or oil that may remain. Dry the surface before the alcohol evaporates to prevent a residue from being left behind.
5. The graphic must be applied in temperatures above 50° F (10° C).

### APPLICATION AND REMOVAL INSTRUCTIONS

1. The size of the FloorTac graphic affects the method of application.
2. For smaller graphics, remove the release liner found on the rear of the print to expose the adhesive. For larger graphics, pull back 3" (76mm) of the release liner on the top of the graphic to expose a small amount of adhesive. Crease the release liner to create a hinge that holds the exposed adhesive away from the floor.
3. Position the graphic in the intended location, using a squeegee to apply the top of the graphic and work down to remove the air as the graphic is applied from the center outward. Overlap the area with each pass to ensure proper air removal.
4. Remove any air bubbles that may remain by pushing them out toward the edges of the graphic with the squeegee. Ensure the floor graphic is attached firmly to the floor surface, especially around the edges.
5. If multiple panels are used, butt the edges together. Do not overlap.
6. Do not scrub or polish the graphic or its surrounding areas for 24 hours after the application.
7. The FloorTac graphic can be removed by pulling an edge back at an angle and using quick tugs. If the floor was previously waxed, it is recommended to wax again once the graphic is removed.

**DRYTAC**  
ADHESIVE SCIENCE

#### Europe

Filwood Road,  
Fishponds,  
Bristol, BS16 3RY,  
United Kingdom  
[bristol@drytac.com](mailto:bristol@drytac.com)  
Tel: +44 (0) 117 958 6500

#### Canada

105 Nuggett Court,  
Brampton,  
Ontario, L6T 5A9,  
Canada  
[toronto@drytac.com](mailto:toronto@drytac.com)  
Tel: +1 800.353.2883

#### USA

5601 Eastport Boulevard,  
Richmond,  
Virginia, 23231,  
USA  
[customerservice@drytac.com](mailto:customerservice@drytac.com)  
Tel: +1 800.280.6013